


WSC-057-F


Wireless Signal Converter

User Manual

WSC-057-F wireless signal converter use to work with wired sensors, the wired sensor NO/NC alarm signal will be converted to wireless FSK 433Mhz signal by connected with WSC-057-F. With the converter, it will make wired sensor working as wireless sensor.



Wired instruction:



Specification:

- Power Supply: DC 12V
- Power output: DC 12V (Can be power for wired sensor)
- Alarm input: NO/NC mode
- Transmitting Distance $\leq 40\text{m}$ (in open area)
- Radio Frequency FSK 433.92MHz
- Operating Condition Temperature: $-10^{\circ}\text{C} \sim +55^{\circ}\text{C}$
- Relative Humidity: $\leq 80\%$ (non-condensing)
- Dimensions (LxWxH) 94 x 45 x 28mm