

WIRELESS 2D BARCODE SCANNER QUICK MANUAL W1.0	Product Introduction This is the simple user's manual, for detailed manual, please download from our website or contact the supplier. (With * is the Default Setting) Factory Default If scanner cannot be used normally due to an error setting, try to scan the "Factory Default" code above. Buzzer Description <table><tr><td>Two medium high voice</td><td>Successful pairing</td></tr><tr><td>One medium long high voice</td><td>Successful scanning</td></tr><tr><td>Three continuous short voice</td><td>Alarm prompt</td></tr></table>	Two medium high voice	Successful pairing	One medium long high voice	Successful scanning	Three continuous short voice	Alarm prompt	Wireless Transmission Mode *2.4G Bluetooth Version Information Scanner Version Information Receiver Version Information	Receiver Pairing 2.4G Receiver Pairing Scanning the "Receiver Pairing" code, scanner will enter the automatic pairing mode for 1 minute, then re-insert the receiver to the host. There will be a sound heard when pairing successfully. Bluetooth HID Pairing Scan the "Bluetooth HID Pairing" barcode, the scanner is ready to be connected by other bluetooth devices.	Interface Type * USB-HID USB Virtual Com Port (Driver is needed for USB Virtual Com Port)
Two medium high voice	Successful pairing									
One medium long high voice	Successful scanning									
Three continuous short voice	Alarm prompt									

Data Transfer Mode * Immediate mode Inventory mode Clear all data Number of stored data Upload all data	Sleep Time Sleep Immediately 1 min * 5 min 30 min	Language *USA France Germany Turkey Q	Language Brazil Italy Spain Universal language *For more languages setting, please refer to the full manual.	Terminator NONE *CR LF TAB CR/LF
--	--	--	--	---