2D Barcode Scanner

User's Manual

HS-V1.0

Product Introduction

This simple user's manual is designed for 2D barcode scanner. For detailed usage manual information, please download the complete user manual from our website or obtain from our distributor.(* default setting)

System Settings



Factory Default



Version Information

Data interface



USB-KBW



RS232



USB Virtual Com

(Driver is needed for virtual serial port)

Note: The data interface is not affected by "factory default ", needs to be configured manually.

Caps Lock



*Original Data



Always Upper Case



Always Lower Case

Terminal Character



None



*CR



TAB



LF



CR/LF

Character delay



No delay



*5ms



10ms

Scan Mode



*Manual



Automatic

Inverse code set



*Inverse code disable



Inverse code On

Language



*US



French



Italy



Germany

Language



Spain



Japan



Russia



Sweden

Language



Turkey



Finland



Universal